




TK SERIES



TK 25K-50K Installation & User Manual

For Europe market

400Vac

Overview

This document mainly introduces the methods of installation, electrical connection, commissioning, maintenance and troubleshooting of the TK series inverters.

Please read this manual carefully before installation and operation to understand the safety information and to familiarise yourself with the functions and features of the TK series inverters.

Personnel requirements

All details in the manual, instructions for installation, operation, maintenance and troubleshooting are intended for authorised installers.

This manual is intended primarily for:










- Hardware Installer.
- Installing and Commissioning Engineer.
- On-site maintenance engineer.
- System maintenance engineer.
- Sales engineer.
- Users.


The end user (inexperienced person) may only use this product after receiving appropriate training from the installer.

Conventional Symbols Used in the Manual and on the Product.

To ensure the safety of people, equipment and everything related to the installation or use of the product, the following warning symbols are included in the manual to remind operators of the safety issues to be followed. Please learn and understand these symbols carefully.

Meaning of symbols in the manual or on the device:

Warning symbol	Meaning of the label
Danger! 	It is used to signal situations of imminent danger which, if not avoided, could result in death or serious physical injury.
Attention! 	Used to warn of potentially dangerous situations that, if not avoided, could result in death or serious physical injury.
Attention! 	Used to warn of potentially dangerous situations that, if not avoided, could cause moderate or minor personal injury.
Note! 	Used to convey equipment or environmental safety warning information that, if not avoided, could result in equipment damage, loss of data, reduced equipment performance or other unpredictable results.
Read instructions 	Read the manual for important critical information, best practices, tips, etc. The 'information you will read' is not safety warning information to be understood as absolute, it must always be interpreted in relation to the environment, the type of installation, the skills of the installer, and the circumstances. Although these warnings contain information about people, equipment or environmental damage, they must always be evaluated in relation to the laws in force and the regulations in force at that location. The principle of maximum safety applies, and if you find any partial information to be incorrect or contrary to local laws, you must not install the inverter/system.
High Voltage 	This label indicates the presence of high voltage inside the product, contact with which may cause an electric shock.
15 minutes waiting time Capacitors present 	This label indicates the presence of capacitors inside the inverter capable of storing energy even after shutdown. Wait 15 minutes after switching off the inverter before performing any work on it.
Hot surfaces 	This symbol indicates that the temperature here is above the acceptable range for the human body and that it must not be touched to avoid personal injury.
Ground connection 	This symbol indicates that this is the protective earth (PE) terminal and that a solid earth is required to ensure the safety of operators.



OPERATIONAL SAFETY PREMISES

Read this manual carefully. Do not install in case of doubt or discrepancy

Hybrid solar inverters and batteries are designed to be safe and reliable when used properly and maintained consistently and diligently. By following these safety and maintenance guidelines, the efficient and safe operation of the system can be ensured, protecting people and property from possible hazards and/or damage. However, to ensure the safety and proper operation of the system, it is essential to follow the safety and maintenance guidelines.

If you have any questions or problems, do not hesitate to contact a qualified technician for assistance.

This inverter should only be installed, maintained and repaired by professional operators.

Safety and Maintenance

1. Proper Use and Regular Maintenance:

- The inverter and the batteries connected to it must be used in accordance with the manufacturer's instructions.

Proper use and constant maintenance are essential to ensure the safety and durability of the system, as well as to maintain the warranty of the various devices connected to it.

- Carry out periodic checks to ensure that all components function correctly and show no signs of wear or damage.

2. Fault Management:

- In the event of a fault, activate all safety procedures immediately. This may include completely disconnecting the inverter from both AC and DC power lines.

- Use external circuit breakers and/or disconnectors, installed and sized according to local standards, to completely isolate the inverter if necessary.

- Never attempt to repair the inverter or batteries yourself. Always contact a qualified technician for any work.

3. Constant Monitoring:

- Constantly monitor the system to ensure that it functions properly. This includes checking the quality of the electricity grid (voltage and frequency) and the status of the solar panels and batteries.

- Variations in the voltage and frequency parameters of the electricity grid, as well as changes in the status of the solar panels and batteries, can affect the inverter's operation, causing standby or idle conditions.

Safety Procedures

1. Disconnection of the Inverter:

- In the event of an emergency or breakdown, follow these procedures:

- Isolate the inverter using the external circuit breakers to disconnect it from the AC and DC power lines.
- Avoid touching electrical parts or internal components of the inverter without first checking for voltage with a voltage tester.
- Disconnect and switch off the inverter when a persistent fault is present.
- Report the fault immediately to a qualified technician or to WeCo.

2. Inspection and Maintenance:

- Carry out periodic checks of the fans, connectors and surfaces to prevent dust accumulation and ensure proper system operation.

- Ensure that the electrical protections are working properly and that the connectors are well tightened.

- Check the grounding of the system annually.

3. Grid Quality Monitoring:

- Check that the grid voltage and frequency are within the expected ranges to prevent the inverter from entering standby or idle conditions.

- Use the inverter monitoring app to receive notifications and alarms in the event of faults or anomalies.

- In case of no voltage or out-of-range grid values, the inverter will necessarily disconnect from the AC grid and this may contribute to the failure to recharge the battery from the grid when necessary.

- Always monitor the inverter and keep it connected to the internet at all times so that you can receive alarm notifications and emails in time to mitigate the problem.

- Ensure that the inverter's internet connection is always active to ensure constant monitoring.



SAFETY INSTRUCTIONS AND GENERAL PRECAUTIONS

General Precautions:

1. LOTO (Lockout-Tagout): Always apply the LOTO procedure to ensure that the inverter is disconnected from all power sources during installation, maintenance or repair. Follow the following steps scrupulously:

- a) Identify all energy sources.
- b) Isolate the energy by physical disconnection.
- c) Lock the isolating devices with safety locks.
- d) Attach warning labels.
- e) Check that there is no residual energy before starting work.

2. Residual Voltage Measurement: Use a certified tester to check that there is no residual voltage on the terminals before proceeding with any operation.

3. Use of PPE (Personal Protective Equipment): Always wear insulating gloves, safety goggles, protective helmet and clothing suitable for electrical work.

4. Grounding: Ensure that the system is correctly earthed and have the earthing check performed at least once a year by a qualified technician, check for certificates and measurements of the earthing before operating, take new measurements anyway.

Scheduled Maintenance Procedures:

- a) Checking and Cleaning Fans (if present):
 - a. Frequency: every 6 months.
 - b. Procedure: Isolate the inverter, remove the protective grids and clean the fans with compressed air. Check that the fans rotate freely and replace any defective components in consultation with the manufacturer in order not to lose the warranty claim and to avoid damaging the inverter parts.
- b) Cleaning Dissipation Surfaces and Parts and Exteriors:
 - a. Frequency: every 6 months.
 - b. Procedure: Isolate the inverter from active connections, power grid, batteries, solar panels, loads on EPS line. Remove dust and dirt from internal and external surfaces using antistatic cloths and a Hoover suitable for electronic components.
 - c. Do not use water, oils, aggressive products or acids to clean system parts.

3. Checking Connector Tightness:

- a) Frequency: every 6 months.
- b) Procedure: Isolate the inverter, check and tighten the AC and DC cable connectors using a torque spanner where possible. Ensure that the connectors are securely fastened to prevent overheating or loss of contact.

4. Checking Tightening of Screws on Battery LV Terminals:

- a) Frequency: every 6 months.
- b) Procedure: Isolate the inverter, use a torque spanner to tighten the screws on the low voltage (LV) battery terminals on both sides. Check for corrosion and replace any defective components.

5. Checking Protections on AC Line Input and EPS Side:

- a) Frequency: every 6 months.
- b) Procedure: Isolate the inverter, visually inspect the protections, check the ratings and correct operation by means of appropriate tests. Replace any defective components.

6. Checking the Release Circuit (Remote Emergency Button):

- a) Frequency: every 6 months.
- b) Procedure: Test the correct operation of the trip circuit by simulating an emergency condition and verify that the inverter disconnects as expected.

7. Internet connection and App:

- a) Frequency: daily.
- b) Procedure: Check the inverter's internet connection, ensure it is up and running. Check the associated App daily to receive notifications and emails in the event of faults or alarms. If there is no internet connection, carry out a daily manual supervision of the system.



GENERAL PRECAUTIONS FOR USERS

General Safety Precautions

Security for End-Users to carry out maintenance and supervision procedures of their plant.

General Precautions:

- a) Do Not Touch Damaged Parts: Do not operate or touch visibly damaged parts of the inverter or solar system. Immediately report any damage to a qualified technician.
- b) Do not touch the rear or side openings of the inverter as they may be very hot.
- c) Earthing: Have the earthing of the system checked annually by a qualified technician.
- d) Cleaning and Maintenance: Do not carry out cleaning or maintenance without authorisation and supervision by a qualified technician.
- e) Daily Supervision: In the absence of an Internet connection, supervise the system on a daily basis to prevent any faults from affecting the functionality of the system.

Permitted and Required Activities:

- a) Check App Connection: Check the inverter's App daily for updates on faults or alarms.
- b) Notification Monitoring: Ensure that you receive notifications and emails from the App in case of faults or alarms.
- c) Reporting Problems: Immediately report any problems or anomalies encountered to the professional installer and await his intervention.

Prohibited Activities:

- a) Work on Electrical Parts: Do not carry out any work on electrical parts or internal components of the inverter, solar panels or batteries.
- b) Self-maintenance: Do not attempt repairs without the supervision of a qualified technician.
- c) Do not alter wiring or the arrangement of wiring, inverters or batteries.
- d) Handling of Components: Do not manipulate or disconnect components of the solar system or inverter.



SUPERVISORY PROCEDURE FOR AN INVERTER

Daily Cadence

1. **System Status Monitoring:**
 - a) Check the general operation of the inverter via the monitoring app.
 - b) Check for alarms or notifications in the app.
 - c) Ensure that the inverter is running and not in standby or idle mode.
2. **Checking the Internet Connection:**
 - a) Check that the inverter's internet connection is active to ensure remote monitoring and notification in the event of faults.
3. **Verification of Production Parameters:**
 - a) Check solar energy production data and battery charge status.
 - b) Compare data with expected data to identify any anomalies.

Weekly cadence

1. **Visual Inspection of Inverter and Batteries:**
 - a) Carry out a visual inspection of the inverter and batteries to identify any signs of wear, damage or overheating.
 - b) Ensure that there are no objects or debris obstructing the inverter's ventilation.
2. **Checking Cables and Connectors:**
 - a) Check that cables and connectors are securely connected and show no signs of damage.
3. **Ventilation System Control:**
 - a) Check that the inverter fans are working properly and that the air intakes are not obstructed.

Monthly cadence

1. **Verification of System Performance:**
 - a) Analysing monthly energy production data to ensure that the inverter is operating correctly.
 - b) Compare the data with those of previous months to identify any negative trends.
2. **Checking the Batteries:**
 - a) Check the state of charge and capacity of the batteries.
 - b) Check for signs of battery degradation, such as swelling or leakage.
3. **Inspection of Electrical Connections:**
 - a) Check the tightness of the connectors and screws on the battery and solar panel terminals.
 - b) Ensure that there are no signs of corrosion or overheating.
4. **Testing of Protection Systems:**
 - a) Verify the functioning of protective devices (circuit breakers, fuses, overload relief systems).
 - b) Test the operation of the emergency release circuit if present.



SAFETY MANAGEMENT AND SUPERVISION OF LITHIUM BATTERY STORAGE SYSTEMS

Lithium batteries, commonly used in solar energy storage systems, require specific precautions due to their potential risk of fire, explosion and toxic gas release. The following are additional safety measures and best practices for handling lithium batteries.

Specific Risks of Lithium Batteries

Risk of Overheating and Burning of Lithium Batteries due to Thermal Runaway.

Excessive discharge and low temperatures contribute to dendrite formation and subsequent cell damage.

Safety Measures:

Lithium batteries can overheat and catch fire if damaged, overcharged or exposed to very high temperatures.

Install the batteries in a well-ventilated room capable of maintaining controlled and, if possible, constant temperatures throughout the year.

A correct installation carried out according to the requirements of the manual contributes to improving the overall safety of the storage system.

Although both inverter and batteries are equipped with active and passive safety systems, residual risks that could cause damage to persons or property cannot be excluded if not well understood and assessed during the design phase.

It is essential to ensure that the site chosen for the installation meets the minimum safety requirements, that it is easily accessible, that it allows agile maneuvering in case of an emergency, that it protects against flooding, and that it is away from combustibles, gases or flammable substances.

Constantly monitor battery temperature using battery management systems (BMS). Avoid overloading by using appropriate chargers and overload protection devices.

Risk of Explosion:

Lithium batteries can ventilate if subjected to physical damage or short circuits.

Safety Measures.

- Protect batteries from shocks and physical damage by using robust housings, marking locations and providing adequate lighting and passive protection against both vertical and horizontal shocks.
- Carry out periodic checks for signs of damage or deformation.
- Use short-circuits protection devices and follow the manufacturer's instructions for installation and use.

Risk of Toxic Gas Release:

In the event of overheating, overcharging, misuse or fire (induced or generated), lithium batteries may release gas from electrolytic gasification.

Normally, the cells ventilate by opening the upper cell valve when the internal pressure exceeds about 150 bar, which allows the release of gas and prevents high internal cell temperatures.

Battery sensors managed by the BMS interrupt charging when the temperature is too high, but still far below the thermal runaway trigger.

Risk of Excessive Battery Discharge

Over-discharge of batteries can irreversibly damage the cells and compromise the safety and efficiency of the system.

Excessive discharge can cause dendrites to form inside the cells, increasing the risk of internal short-circuits and fires.

Actions to Take in the Event of Excessive Discharge:

Monitoring: Ensure that the charge levels are above the minimum permissible level, check that the inverter is connected to the AC grid.

Isolation: If a battery becomes excessively discharged, isolate it immediately from the rest of the system to prevent further damage.

Inspection and Replacement: Have a qualified technician carry out a thorough inspection. If the battery is damaged, replace it with a new one.

Preventive Maintenance:

Schedule regular maintenance to check the state of the batteries and prevent excessive discharges.

Set up the APP to notify important events.

Monitor AC-side inverter power switches to ensure emergency charging of batteries in case of low voltage and/or lack of sufficient solar production to charge batteries.

Monitor photovoltaic fuses or breakers to ensure energy production from photovoltaic panels.

Safety Measures.

- Install gas detectors and adequate ventilation systems in battery installation areas for increased safety.
- Evacuate the area immediately if gas or a burning smell is detected.
- Use respiratory masks and other personal protective equipment in case of emergency.

Best Practice for Emergency Management of Storage Plants with Inverters, Solar Panels and Lithium Batteries.

In Case of Overheating or Smoke:

- Immediately isolate the inverter and batteries by operating an emergency button that acts universally on the circuits.
- Evacuate the area and call the emergency services.
- Do not attempt to extinguish the fire with water; use CO₂ or powder extinguishers if available.
- Inform the fire brigade that these are lithium batteries.

In Case of Fire:

- Use CO₂ or powder extinguishers specifically designed for lithium batteries.
- Evacuate the area and call the emergency services.
- Do not attempt to extinguish the fire with water.

Maintenance and Prevention:

Carry out regular checks of the system internally including the condition of the batteries.

Ensure that the batteries are installed in a suitable environment and protected from physical damage. Strictly follow the manufacturer's guidelines for the installation, use and maintenance of lithium batteries.

Important Notes:

The direct current supplied by solar panels and batteries can be extremely dangerous. It is essential that only qualified personnel carry out operations involving the installation, maintenance and repair of the inverter and associated system.

Table of Contents

Overview	2
1 Safety Instructions	9
1.1 General safety considerations.....	9
1.2 Statement	10
1.3 System Installation	10
1.4 Electrical connections	11
1.5 Procedures	11
1.6 Maintenance and Replacement	12
2 Product Introduction	13
2.1 Product Introduction	13
2.2 Description of appearance	13
2.3 Terminals of inverter	14
2.4 System Topology	15
3 Pre-installation	16
3.1 Check the outer packaging	16
3.2 Packing list	16
3.3 Installation tools and gauges requirement.....	16
3.4 Installation requirement.....	18
3.5 Cable Preparation	20
4 Installation	21
4.1 Steps instructions	21
4.2 Installation Steps	22
Step 2: Connect the PE cable to inverter.....	23
Step 4: Connect the Battery to TK inverter.	24
Step 5: Connect the AC cables to TK inverter	26
Step 6: Connect Meter to TK inverter	27
5 System Commissioning	29
5.1 Power-up checklist	29
5.2 System power up	30
5.3 Commission on APP	30
5.4 Energize the system.....	34
6 System Maintenance	35
6.1 Routine Maintenance	35
6.2 Power down the system	36
6.3 System power-up.....	36
6.4 Troubleshooting	37
7 Storage & Care.....	39
7.1 System Storage	39
7.2 System Care	39

8 Inverter Disposal	40
8.1 Remove the inverter.....	40
8.2 Packaging inverters.....	40
8.3 Scrap inverters.....	40
Appendix A abbreviations	41
Appendix B Label Description.....	42
Appendix C Technical Datasheet.....	44
Appendix D Working Mode & Light Language	50
Appendix E Noor APP User Guide	54
App Introduction	54
Download and install the app	54
Register a Noor APP account	55
Login and Logout of the APP.....	55
Build a Power Station Wizard	56
Add new device.....	57
Check the plant status.....	59
Basic settings.....	61
Device running information.....	67
Device management	67
Plant Management.....	68
Link to Manuals.....	70
Account Management.....	71
Setting	71

1 Safety Instructions

1.1 General safety considerations



Note!

- This manual is an integral part of the inverter and describes the assembly, installation, commissioning and maintenance of the product. Please read it carefully before beginning any operation.
- Personnel responsible for inverter operation, product installation, electrical connection, commissioning, maintenance and troubleshooting must be qualified electricians and must be trained to use the correct operating methods in accordance with the laws of the state in which the inverter is used.
- Any person involved in the operation, installation and maintenance of the inverter must be trained and supervised by a company safety officer regarding the interaction between the inverter and the local electrical system and possible interference with other existing infrastructure.
- WECO is not responsible for the installation process or the selection of installers, who must be qualified according to local regulations. WECO assumes no responsibility for violations of general operational safety requirements or safety standards for the installation and use of the equipment.

All information and advice contained in this documentation does not constitute an express or implied action contrary to local regulations or standards. The safety guidelines included in this document may not include or consider all applicable regulations in the area of installation/operation. Always review and consider applicable federal, state, and local laws and regulations in accordance with product industry standards.

WECO cannot be held liable for malfunctions or damage caused in such circumstances:

- Shipping damage.
- Damage caused by storage conditions that do not comply with the requirements of the product documentation.
- Improper storage, installation and use of the equipment.
- Unqualified personnel using and operating the equipment.
- Damage caused by third parties during improper installation or maintenance.
- Damage caused by non-compliant installation of devices connected to the inverter
- Failure to observe the operating instructions and safety warnings contained in the product and documentation.
- Operating in harsh environments beyond what is described in the product and documentation.
- Operations and settings that go beyond the parameters specified in the applicable technical specifications.
- Unauthorised disassembly and/or repair, alteration of the product or modification of the software code, installation of inappropriate firmware.
- Equipment damage caused by abnormal natural environments (such as lightning, earthquakes, fire, storms, etc.).
- The warranty period has expired, and the warranty service has not been extended.
- Any installation and operating environment outside of those specified by relevant standards.

1.2 Statement

Personnel capable of installation, cabling, commissioning, maintenance, troubleshooting and replacement must meet the following criteria:

- Operators must receive professional training from their employer before operating devices for the first time.
- Operators must read this manual in its entirety and master safety issues related to operation.
- Operators must be familiar with the relevant safety specifications of electrical installations.
- The operator must know the operating principle and composition of photovoltaic storage systems and be familiar with the user manual for this product.
- During operation, do not wear metal objects such as rings, watches, key rings, etc., and always wear personal protective equipment (such as insulating gloves, insulating shoes, etc..).
- Installers or company managers must train and inform the end customer in the ordinary use of the inverter and train them on emergency management, how to interact with safety devices and how to interpret alarms or warnings indicated in the APP.
- The markings on the inverter contain important information for safe operation. It is strictly forbidden to alter or damage the casing and/or the safety markings on the frame.
- The inverter is equipped with a nameplate on the side which contains important information on product parameters. Alteration is strictly forbidden.

1.3 System Installation



Danger!

It is strictly forbidden to use the inverter connected to any source of electricity during installation at first start-up and in any case during maintenance or troubleshooting, the inverter must first be switched off and then switched on in sequence to exclude injury or damage. Ensure that all power sources are disconnected when installing the inverter. Lock and label all power sources so that they cannot be switched on before installation is complete.

- The process of lifting and positioning the inverter must be performed slowly and safely, the product could be damaged and operators could be injured.
- When installing the inverter, ensure that it is not electrically connected to any power source.
- There must be at least the distance specified in the manual between the inverter and surrounding objects to ensure sufficient space for installation and heat dissipation. If you have any questions about the installation distance, please consult a service technician.
- During installation, avoid liquids, debris or conductive particles entering the system, which could cause internal short circuits or system failure.
- Do not install on rainy or particularly humid days as waterproof connectors, once opened, may retain moisture and then once closed may oxidise internally and become dangerous.

1.4 Electrical connections



Danger!

Before making any electrical connections, ensure that the inverter is undamaged and carry out installation only under safe conditions.

Avoid installing the inverter where there is visible damage to prevent electric shock, fire and personal injury.

Do not install the inverter if there is any damage to the inverter housing or metal casing.

- All electrical connections must comply with national electrical regulations. If the procedures in this manual or the information contained herein conflict with local laws, do not install the product and consult your technician and/or supplier.
- The equipment must be permanently connected to a protective earth. When installing equipment that must be earthed, the earthing cable must be installed first. When disassembling the equipment, the earth cable must be removed last.
- External cables must be protected in cable ducts or pipes and reliably secured with cable clamps and brackets. Buried cables must be marked with special burying markers and then backfilled ensuring that no deformation or damage caused by stresses on the cables occurs during backfilling or later.
- The inverter may only be connected to the grid with the permission of the local energy authority in accordance with the regulations in force at the time.
- The cables used in the system must be securely connected, well insulated and of adequate specification.
- The use of cables in high-temperature environments can cause the insulating layer to age and damage the cables. The distance between cables and heating devices or heat sources must be at least 30 mm.
- When the temperature is too low, shocks and vibrations can cause the cable's plastic outer jacket to break. All cables must be laid and installed at a temperature above zero, especially in low-temperature environments.
- Cable specifications are different for grid, battery and photovoltaic connection. These requirements must be strictly adhered to.
- All DC cables must be installed in such a way as to provide as short a path as possible, and the positive and negative cables of the string or main DC supply must be bundled together. Avoid creating loops in the system.

1.5 Procedures



Danger!

High-voltage inputs to the inverter are dangerous. Please strictly follow the safety precautions listed in this manual and other relevant documents.

Always follow LOTO procedure to avoid serious safety risks.

- When the ESY is switched on for the first time, it must be configured by a professional electrician.
- Incorrect settings can impair the proper functioning of the inverter and result in the inverter not conforming to the country's certification.
- Some inverter components, such as copper bars, inductors, etc., take some time to cool down after being switched off. Do not touch them immediately after a power failure and beware of burns.
- Use the equipment in accordance with local rules and regulations.
- Capacitors in the inverter are subject to slow discharge, so wait 15 minutes before working inside the inverter and ensure that all terminals have 0V by checking with a voltmeter.

1.6 Maintenance and Replacement



Danger!

When using the inverter, be aware that the DC and AC inputs and outputs are "high voltage" and can cause electric shock, resulting in death, serious injury or property damage.

Therefore, before performing any maintenance work, you must turn off the power, wait 15 minutes and work in strict accordance with the safety precautions listed in this manual and other relevant documents.

- Only service the Inverter if you are familiar with the contents of this manual and have the appropriate training, tools and test equipment.
- Before maintenance, turn off the inverter, input and output switches, and wait at least 15 minutes before performing any operations on the inverter.
- During maintenance sessions, avoid access of unrelated personnel to the maintenance site and place temporary warning signs or fencing to isolate.
- The inverter may only be re-powered after the fault has been resolved, otherwise the fault may expand or the equipment may be damaged.
- During maintenance, follow ESD protection specifications and wear antistatic equipment.
- Avoid opening cabinet doors in wet or rainy weather for maintenance or repair of products.
- When carrying out various operations such as maintenance and inspection of equipment, competent personnel must take appropriate protective measures, such as wearing noise-reducing earplugs, insulating shoes and anti-scald gloves.

2 Product Introduction

2.1 Product Introduction

The inverter is a three-phase converter, capable of converting solar energy into alternating current or storing DC energy in the battery for use when needed. The user can use the app to flexibly choose the most advantageous operating mode according to the actual usage scenario, with different situations of PV, grid, battery, load and so on.

3)With energy management system on APP, The user can monitor and manage the energy storage system easily.

Inverter Model

This paragraph defines product models: TK-25K-XL, TK-30K-XL, TK-36K-XL, TK-40K-XL, TK-50K-XL, TK-40K-HC, TK-50K-HC. Naming convention TK (using TK-50K-HC as an example):




Figure 2-1

2.2 Description of appearance




Figure 2-2

2.3 Terminals of inverter




Figure 2-3

NO.	Terminal	Description
A	DC switch	DC switch for PV1 and PV2
B	DC Input terminal	PV input port
C	DC switch	DC switch for PV3 and PV4
D	Battery input terminal	Battery connector
E	COM2	COM2 interface for Meter/BMS/RS485/DRED/DO Connector
F	COM1	COM1 interface for WIFI module terminal
G	COM3	COM3 interface for DO/0-10V AO/4-20mA AO Connector
H	On-Grid input terminal	Used for On-grid input cable connection
I	Generator input terminal	Generator connector (Available in the future)
J	Backup Load output terminal	Used for Back-up output cable connection
K	LED Bar	Display working states of the inverter.

2.4 System Topology

For proper operation of the EPS load, make sure that the maximum load power of the EPS is within the limits of the inverter, otherwise the system will not be able to support the EPS in case of power failure and an overload alarm may occur. (Refer to the product data sheet).




Figure 2-4

*GENERATOR: Future function, generator connection function is under development.

3 Pre-installation

3.1 Check the outer packaging

Before unpacking the inverter, check the outer packaging for visible damage, such as holes, cracks, or other signs of possible damage inside, and check the inverter model. If the packaging has abnormalities or the inverter model does not match, do not open it and contact your dealer as soon as possible.

3.2 Packing list

Check Deliverables




After unpacking the inverter, check that the delivery is complete and that there is no obvious external damage. If missing or damaged, contact your dealer.






















The following is the packing list for reference only, product deliveries are based on the actual packing list inside the box, if you have any questions about deliveries please contact your dealer.

Table-1 Packing list (Reference only)

No.	Packed Accessories Name	Quantity (PCS)
1	Hybrid Inverter	1
2	Inverter bracket	1
3	Expansion Bolt assembly	4
4	M6 Steel Cross Groove Screw	2
5	AC connector set	3
6	PV terminal pairs	8
7	Battery pairs	1
8	Meter with 3 CTs	1
9	COM2 connector set	1
10	COM3 connector set	1
11	PE terminal	2
12	WI-FI Module	1
13	10m Meter communication cable	1
14	3m Battery communication cable	1

3.3 Installation tools and gauges requirement

Installation	 <p>Hammer drill (drill bit $\Phi 8\text{mm}$).</p>	 <p>Torque socket wrench (sleeve opening: 8mm, for M6 bolts; Torque range: 0N•m~ 15N•m).</p>	 <p>Torque wrench (opening size: 13mm; Torque range: 0N•m~1.5N•m).</p>
---------------------	---	---	---

	 <p>Diagonal pliers</p>	 <p>Wire strippers</p>	 <p>Torque screwdriver (head: M4, M6; Torque range: 0N•m~ 5N•m).</p>
	 <p>Rubber hammer</p>	 <p>Tool knife</p>	 <p>Wire cutters</p>
	 <p>Crimping pliers (Model: H4TC0001; Manufacturer: Amphenol).</p>	 <p>Open Wrench (Model: H4TW0001; Manufacturer: Amphenol).</p>	 <p>Cable ties</p>
	 <p>vacuum cleaner</p>	 <p>Multimeter (DC voltage range \geq 600V DC).</p>	 <p>Markers</p>
	 <p>Steel tape measure</p>	 <p>Horizontal ruler</p>	 <p>Hydraulic pliers</p>
	 <p>Heat shrink tubing</p>	 <p>Heat guns</p>	
Personal protective equipment	 <p>Safety gloves</p>	 <p>Protective goggles</p>	 <p>Dust masks</p>
	 <p>Safety boots</p>		

3.4 Installation requirement

- 1) Inverter installation must comply with local fire regulations (consult your company's safety department for details).
- 2) Do not install the inverter near flammable materials, liquids or gases; The installation site must be approved by local authorities.
- 3) Ensure that the installation surface is strong enough to support the inverter and that the supporting screws are capable of meeting the load requirements of the inverter installation.
- 4) Inverters must be marked and confined to a dedicated area, room or technical compartment, must not be accessible to third parties, and must be illuminated for safe operation.
- 5) Post signs, in the immediate vicinity, warning and danger for the presence of solar inverters connected to batteries and solar panels.
- 6) Inform the person responsible for managing the electrical system of the presence of the solar inverter and batteries, update the electrical diagrams of the buildings.

Installation environment requirements

- 1) The inverter has an IP65 degree of protection and can be installed outdoors, although it is recommended to install it in a protected environment to prolong its service life and performance
- 2) The inverter should be installed in a well-ventilated environment to ensure good heat dissipation. (Do not install the inverter outside without any weather protection/shielding.
- 3) WeCo suggests that installation take place in dedicated technical rooms in order to maximize the safety and durability of the system.
- 4) The installation location of the CT or digital meter should be close to the grid meter, refer to the CT connection section or digital meter section for more details.
- 5) Do not install inverters in areas where flammable and explosive materials are stored.
- 6) Do not install inverter in a place that can be reached by children.
- 7) Inverter installed in the salt-damaged area will be corroded and may cause fire, do not install the inverter outdoors in the salt-damaged area. Salt-damaged areas are areas within 500 to 800 meters from the coast or affected by sea breezes. Areas affected by sea breezes vary depending on weather conditions (e.g. typhoons, seasonal winds) or terrain (with dikes, hills).
- 8) Keep away from direct sunlight, exposure to rain, and snow accumulation. It is recommended to choose a sheltered, ventilated, dry, and safe installation site for inspection and maintenance activities. It should be accessible, clearly visible, and easily accessible even by third parties, for safety reasons.
- 9) It must be marked that the installation is equipped with a photovoltaic system with batteries, and it must be clearly indicated to the procedure for shutting down and isolating the system from the rest of the system Batteries, if installed, must be installed in accordance with the battery manual.
- 10) Batteries must be installed in a safe place, and in a dedicated technical room, in a place not subject to the stationing of people.
- 11) Do not install batteries outdoors even if they have an IP54 or higher rating as the battery may be exposed to widely varying temperatures that could affect its capacity and performance.




Figure 3-1

Installation space requirements

When installing the inverter, a certain amount of space should be reserved around the inverter to ensure that there is enough space for installation and heat dissipation.

And do not install the inverter too high, Installing the inverter too high is not conducive to heat dissipation, installation, and maintenance. The height of installation is recommended 1500mm from the floor to the bottom of inverter. For more detail, please refer to the figure3-2.





Figure 3-2

In case of multiple inverters, reserve specific space between the inverters.



3.5 Cable Preparation



Note!

Disconnect the external AC circuit breaker or another AC load circuit breaker to ensure safe disconnection of the inverter from the grid. and the single-phase circuit breaker connected to the inverter should be based on the rated output current of the inverter model.

If the external AC circuit breaker has a leakage protection function, its rated leakage operating current should be $\geq 100\text{mA}$.

Make sure the grounding wire of the inverter is well connected to ensure safety and reduce leakage current.

The use of knife switches is prohibited for interrupting the AC circuit.

The switches below are recommended by WECO. For any other selection, please choose the cable according to local regulations.

Relevant Cable & wires introduction

The cables shown below are recommended by WECO but must still be validated by the design engineer in your electrical design. Choose the cable according to local standards and design specifications.

No.	location	Description	Wire (mm ²)	Source
1	PV input cable	PV power input line, Based on inverter model	10	Provided by Installer
2	Battery input cable	Battery power input line, use to connect with battery power terminal	16	
3	Grid-side input cable	Grid power input line, use to power the inverter system	Based on inverter model	
4	Back-up load output cable	Back-up Load power line, use to connect EPS load port	Based on inverter model	
5	PE connection cable	PE cable connect the outside of inverter to PE bar;	6	
6	CT or Digital Meter communication cable	CT use to jig on the Grid-L line to active Back up, Anti-reflux functions		Provided by WECO
7	WECO battery communication cable	Battery communication cable connect the battery and inverter		Provided by WECO

4 Installation

Before installing the TK series inverter, please read this manual carefully.



Danger!

Before making the electrical connection, make sure that all the switches of the inverter are in "OFF" state, otherwise the high voltage of the inverter may cause the risk of electric shock.



Warning!

- Equipment damage caused by incorrect wiring is not covered by the equipment warranty.
- Work on electrical connections should be carried out by professional electricians.
- When making electrical connections, personnel must wear personal protective equipment.
- Placing installation tools, metal parts and debris on the inverter during the installation process is strictly prohibited. After installation, promptly clean the inverter and surrounding objects.
- After completing the wiring or after interrupting the wiring process, the cable opening must be sealed immediately to prevent the entry of water vapor or small animals.



Note!

Only qualified professionals are allowed to install this product. Before installing the inverter, follow the instructions for the use of personal protective equipment; Also, due to the weight and safety of the inverter, it is recommended that the inverter be installed by two people.




Read Info

The color of the cable involved in all electrical connection diagrams in this section is for reference only, and the cable selection should comply with the local cable standards.

4.1 Steps instructions

To better guide installation personnel, this chapter explains step by step how to install an ESY series inverter system. Referring to the image below, break down the installation steps into:




4.2 Installation Steps

- Step 1: Install the TK inverter on a wall.
- Step 2: Connect the PE cable to TK inverter
- Step 3: Connect the PV strings to TK inverter.
- Step 4: Connect battery to TK inverter.
- Step 5: Connect EPS Loads to TK inverter.
- Step 6: Connect the AC Grid to TK inverter.
- Step 7: Connect CT to TK inverter.
- Step 8: Connect WIFI Dongle to TK inverter.


Step 1: Install the TK inverter on a wall

- a. Use a drill tool to make 4* $\phi 8 \times 55$ mm holes on the wall according to the mounting holes position of the mounting bracket. (The hole depth during 50-60mm)
- b. Install the plug in the holes, then tighten the M6*35mm screw to lock the bracket on the wall.

a. Mark the holes.




b. Fix the bracket on the wall.




- c. Lift the inverter, hang it up on the wall bracket, align the holes of inverter with the holes of the wall bracket.
- d. Fix with 2*M6 screws on the left and right side to fasten the inverter on the bracket.

c. Hang up the inverter.




d. Install the back bracket on the rear.



Step 2: Connect the PE cable to inverter.

- (a) Make the OT terminals for PE cable.
- (b) Protect the the conductor with a heat shrink tube.
- (c) Connect to the PE terminal on the right side of inverter inside.

- 1. Make the OT terminal for "PE" cable.
- 2. Put on the heat shrink tube.
- 3. Fasten PE cable.




Step 3: Connect the PV strings to TK inverter.

Make the PV+ connector:

- (a) Strip the 10mm conductor of PV+ and insert the conductor into the Male Pin.
- (b) Using a crimping tool to crimp the cable end of PV+, then
- (c) Put the PV+ end to the PV+ connector and fasten the screw.


- a. Put the PV+ to Male Pin.
- b. Crimp the PV+.
- c. Make the PV+ connector.




Make the PV- connector:

- (a) Strip the 10mm conductor of PV- and insert the conductor into the Female Pin.
- (b) Using a crimping tool to crimp the Cable end of PV-, then
- (c) Put the PV- end to the PV- connector and fasten the screw.

- a. Put the PV- to Female Pin.
- b. Crimp the PV-.
- c. Make the PV- terminal.




Connect each PV sting to TK PV terminal:




Step 4: Connect the Battery to TK inverter.

Make the Bat connector:

- (a) Strip the 10mm conductor of Bat and insert the conductor into the Pin.
- (b) Using a crimping tool to crimp the cable end of Bat
- (c) Put the Bat+ end to the Bat+ connector and fasten the screw.



Connect the power cable of the HV Box to TK inverter.




Connect the Communication cable between Battery and TK.

Connect the battery to the TK COM2 with a special RJ45 cable from the accessory.


- (a) Thread the RJ45 plug of appropriate length through the swivel nut, and insert it into the open side of the rubber gasket.
- (b) Insert one side of the RJ45 plug into the RJ45 port of terminal block.

a.

Open side



b.



Note!

If LAN cable need to be prepared onsite, refer to the cable definition in the following figure 4-1. The color order at both ends is different.









Figure 4-1

Step 5: Connect the AC cables to TK inverter



- Make the PIN terminal ends for L1, L2, L3, N, PE of AC cables.
- Use a crimping tool to crimp all cable ends.
- Run the cable gland and connect it to the connector.
- Plug the wire ends into the corresponding L1, L2, L3, N, PE positions on the connector. Then fasten the screw to lock it.




Step 6: Connect Meter to TK inverter

The current Transformer, also called CT, must be installed on the L wires between of the power grid.


The Meter can be installed in the AC combiner box or other appropriate places. Standard CT cable with length of 2m, it's fixed and can't be extended.

Meter connection




Fault CT connection cases


Case1: Connected to wrong Line



Case2: Wrong Orientation



Case3: Connected to wrong Line




⚠ Note!

CT installation direction should strictly follow the instruction in the user manual, otherwise, the inverter may not be working normally. The connection between CT and Meter needs to be reliable, otherwise, the CT measurement accuracy may be affected.

Connect the Communication cable between Meter and TK inverter.


Connect the battery to the TK COM2 with a special RJ45 cable from the accessory.

- (a) Thread the RJ45 plug of appropriate length through the swivel nut, and insert it into the open side of the rubber gasket.
- (b) Insert one side of the RJ45 plug into the RJ45 port of terminal block.



Meter Overview


Meter terminals definition as shown in table below:



NO.	Definition		Function
	ACR10R	SM	
1	L1		L1/L2/L3/N connect to grid to detect power grid voltage
2	L2		
3	L3		
4	N		
5	L1-S1		To detect the CT current and direction
6	L1-S2		
7	L2-S1		
8	L2-S2		
9	L3-S1		
10	L3-S2		
11	/	PE	Ground connection
12	L	/	Power supplied from grid
13	N	/	
RS485	/	Reserve	Communicate with hybrid inverter
	RS485	RS485-2	
ANT	/	Reserve	
LAN	/	Reserve	
Type-C	/	Type-C	Specified Debug Interface. Do not use it by non-professionals

Step7: Connect WIFI dongle to TK

Connect the WIFI dongle to TK COM terminal.



5 System Commissioning

5.1 Power-up checklist



Note!

- Please check the following checklist before turning on the system for the first time; otherwise, the device may be dangerous or damaged.
- Always consult local regulations, wear appropriate personal protective equipment during operations for your own safety.
- Before checking or starting, make sure the power is off and there is no electricity, to avoid damage and risk to people.
- The operation can only be performed by authorized persons or licensed electricians.

First Power on - Preparation Checking items and acceptance criteria

Item	Check the item	Acceptance Criteria
1	Inverter installation	The inverter is installed correctly and is robust and reliable. 1. The installation space is reasonable, the environment is clean and tidy, and there are no construction residues.
2	Switches	1. All power switches connected to the inverter are in the "OFF" state.
3	Cables management	1. Cable arrangement is reasonable to meet the user's needs and in accordance with local regulations
4	Grounding	1. Ground wire connection is correct and reliable
5	AC Grid connection	Inverter network input cable L, N, PE is well connected to the main panel switch. 1. The CT is fixed on the right grid cable (phase L) and well tightened.
6	DC PV Connection	Ensure that the PV panels are well grounded. Ensure that all PV cables are well connected and insulated without damage or exposed. Check the number of PV panels in each string and the open-circuit voltage of the PV panel, making sure that it does not exceed the maximum MPPT voltage. 1. Check PV panel operation and open circuit current, making sure that all limits are within the MPPT ampere range.
7	DC Battery connection	Ensure that the power connections between battery and inverter are made according to the requirements of the relevant manuals and make sure that the tightening torque is correct. 1. Ensure that the RJ 45 battery communication terminal is properly connected to the BMS CAN port of the inverter.
8	AC Load connection	1. Make sure the load cable L, N, PE are well connected to the load switch.
9	Inverter communication ports	Make sure that all terminals are well connected and that unused terminals and connections are covered with waterproof covers. 1. Ensure that the WiFi antenna is installed correctly.
10	Plastic brackets and ties	Ensure that with create hindrance or sharp corners after cutting.


5.2 System power up

Prerequisites

Before closing the AC switch between the inverter and the grid, it is necessary to measure whether the AC voltage on the grid side of the AC switch is within the range allowed by the inverter.

Procedure

Step 1: Turn on the inverter to activate the WiFi device and configure the inverter. Close only the AC switch between the inverter and the grid if the inverter is connected to the grid. If the system is offgrid, start-up by turning on the batteries.



5.3 Commission on APP

Procedure:

Step 1: Download and install the app





Search for "Noor" in the Google Play or App Store application market.




Step 2: Register Noor APP account and Sign in Noor APP

- Click "Register".
- Fill in the account info step by step and Click "Register Now!".




c. Fill in the account and password and Click “Sign In”.



Step 3: Add Plant on Noor APP


a. Click “Add Plant”.

b. Fill in the Plant info and Click “Save”.




Step 4: Add Device on the Plant and config the WIFI module


- a. Click "Add Device".
- b. Click the "Datalogger".
- c. Scan the QR code of WIFI module or manual input WIFI module SN number and Click "Adding" to finish add device.




- d. Click "Smart config" to config the WIFI module to homeowner Router step by step.




Step 5: Inverter setting

a. Click the icon  and “Basic Setting” to enter the inverter basic setting page.




b. Click the “Expert Setting” and input the password to enter the advanced setting page.




5.4 Energize the system

After finishing all the commission steps, installer can power on the inverter step by step.

Step 1: If the inverter is connected to the battery, close the battery breaker first and then turn on the battery.



Step 2: If there is a PV breaker between the inverter and the photovoltaic string, close the breaker. Then turn the "PV SWITCH" located on the left side of the inverter in the "ON" position.



Step 3: Observe the LED indicator to check the operating status of the inverter.

6 System Maintenance

6.1 Routine Maintenance

In order to ensure that the inverter can operate well for a long time, it is recommended to maintain it routinely as described in this section.



Caution!

- Perform system power-down operations while performing maintenance such as system cleaning, electrical connections, grounding reliability, etc. (see 6.2 System Power-down).
- Please use specialized protective equipment and insulation tools to avoid electric shock injuries or short circuit faults.
- It is prohibited to use a damp cloth to clean exposed copper bars or other potentially conductive parts, and it is also prohibited to use water or any solvent to clean the inverter.
- It is prohibited to maintain the inverter with electricity, and operations such as checking and tightening screw torque require the battery to be powered off. Only after taking effective preventive measures can operations be carried out.
- When it is necessary to move or rewire, the power input must be cut off, and after waiting for 15 minutes, the internal energy of the machine is fully discharged. After confirming with a multimeter that there is no dangerous voltage on the DC bus and the parts to be repaired inside the machine, maintenance can begin.

Maintain lists

Check the content	Check the method	Maintenance cycles
System cleaning	Regularly check the dust inside the box for dirt	Every six months to 1 time in a year
System operating status	Observe whether the appearance of the inverter is damaged or deformed. Listen to whether there is an abnormal sound during the operation of the inverter. When the inverter is running, check whether the parameters of the inverter are set correctly.	1 time every six months
Electrical connection	Check the cable connection for detachment and looseness. Check the cable for damage, focusing on whether the skin of the cable in contact with the metal surface has any traces of cuts.	Half a year after the first commissioning, and then once every six months to a year.
Grounding reliability	Check that the grounding cable is reliably grounded.	Half a year after the first commissioning, and then once every six months to a year.
Devices reliability	Check the battery (if there is), generator (if there is), PV strings, grid stability status	Half a year after the first commissioning, and then once every six months to a year.

6.2 Power down the system



Warning!

- After the inverter is powered down, there is still residual power and heat in the chassis, which may cause electric shock or burns. Therefore, after 15 minutes of powering down the inverter system, wear protective gloves before operating the inverter.
- If the inverter is connected to a battery device, please make sure to use the APP to issue a shutdown command, and after the inverter has been turned off, perform the power-down operation.
- If the user does not use the APP to issue the shutdown command, the inverter will switch to off-grid working mode after the power down on the grid side.

Procedure

Step 1: Use the APP to issue shutdown commands.

Step 2: Disconnect the inverter and the AC circuit breaker input on the grid side.

Step 3: Disconnect the PV DC circuit breaker between the inverter and the PV string.

Step 4: If the inverter battery port is connected to a battery device, disconnect the battery input circuit breaker.

6.3 System power-up

Prerequisites

Before closing the AC switch between the inverter and the grid, it is necessary to measure whether the AC voltage on the grid side of the AC switch is within the allowable range of the inverter.

Before closing the inverter and the PV DC input switch, it is necessary to measure whether the DC voltage on the PV DC switch side is within the allowable range of the inverter.

Before closing the DC input switch between the inverter and the energy storage device, it is necessary to measure whether the DC voltage on the DC switch side of the energy storage device is within the allowable range of the inverter.

Procedure:

Step 1: If the inverter energy storage port is connected to an energy storage device, close the energy storage switch first, and then the auxiliary power switch of the energy storage device.

Step 2: Close the AC switch between the inverter and the grid.

Step 3: If there is a DC SWITCH between the inverter and the photovoltaic string, close the DC SWITCH.

Step 4: Place the "DC SWITCH" located on the left side of the inverter in the "ON" position.

Step 5: Set the inverter parameters through the App, see "Noor Cloud APP Operation".

Step 6: (Optional) Use a spot thermometer to detect the temperature at the connection between the DC terminal and the energy storage terminal. After the inverter has been working for a period of time, the temperature at the DC terminal connection is detected to confirm that the DC terminal contact is good. Make sure the temperature rise does not exceed 30°C.

Step 7: Observe the LED indicator to check the operating status of the inverter.

6.4 Troubleshooting

The fault messages and their corresponding troubleshooting methods are listed below:

Error/Fault Message	Description	Solution
Grid Lost	Grid power outage, AC switch or circuit is disconnected.	(1). Confirm whether the grid supply is lost. (2). Check whether the AC breaker and terminal are well connected.
Grid Voltage Fault	The inverter detects that the mains voltage is outside the limit of the selected safety range.	(1). Check whether the safety code is correct. (2). Check whether the AC cable wiring is correct. (3). Check whether the voltage increase is caused by a high impedance of the AC cable. In this case, the cable can be replaced. (4). Verify with the approval of the Electricity Authority whether it is possible to change the limit.
Grid Frequency Fault	Grid over frequency or under frequency, the grid frequency is higher or lower than the set protection value.	(1). Check whether the AC cable is correct and well connected. (2). Verify with the approval of the Electricity Authority whether it is possible to change the limit.
DCI Fault	Inverter detects that the the direct current injection value exceeds the range.	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
ISO Over Limitation	Inverter detects that DC side's insulation impedance to the ground is too low.	(1). Check whether PV panels, cables, and connectors are waterlogged or damaged. (2). Use a megohmmeter to measure ground resistance on the DC side, and the measured value should not be less than 500 kΩ. (3). If the problem persists, contact the installation company.
GFCI Fault	The inverter detects that the ground leakage current exceeds the limitation.	(1). Restart the inverter. (2). Check whether the PV panels, cables, and connectors are waterlogged or damaged. (3). If the problem persists, contact the installation company.
PV Over Voltage	PV input voltage exceeds the upper limit.	Reduce the number of PV panels to make sure that the open-circuit voltage of each string is lower than the inverter maximum allowed input voltage.
Bus Voltage Fault	The voltage of bus circuit is too high	(1). Check whether the input voltage exceeds the limit. (2). Restart the inverter. (3). If the problem persists, contact the installation company.
Inverter Over Temperature	The inverter detects its high internal temperature.	(1) Check whether the inverter installation location is well ventilated. (2) Try to turn it off for a while, and then power it back on when it cools down. (3) If the problem persists, contact the installation company.
N - PE Check Fault	The ground cable is loss or in poor connection	Check whether the ground cable wiring is correct.
SPI Fault	Internal communication got failed. Caused by a strong external magnetic field etc.	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
E2 Fault	Internal storage got abnormal. Caused by a strong external magnetic field etc.	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
GFCI Device Fault	GFCI device got abnormal	(1). Restart the inverter. (2). If the problem persists, contact the installation company.

AC Transducer Fault	AC transducer got abnormal	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
Relay Check Fail	Self-checking of internal relay got failed. Neutral & ground cable are in poor connection on AC side.	(1). Use multimeter to measure the voltage between N&PE cable on AC side. If the voltage is higher than 10V, which means the neutral or ground connection is abnormal. (2). Restart the inverter. (3). If the problem persists, contact the installation company.
Internal Fan Fault	Inverter's internal fan got failed	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
External Fan Fault	Inverter's external fan got failed	Check whether the fan is blocked by foreign matters, clean them if necessary.
Bat OV	Battery protection triggered	(1). Check the battery status and whether the alarm is actually triggered on the battery side. (2). Restart the system.
Backup OV	Abnormal voltage on the back- upside	Turn off inverter and remove the back-up connector. Use a multimeter to measure whether there is voltage existing on the back-up connector.
Bus Volt Low	Abnormal voltage on the DC inverter BUS	Check whether the battery voltage and PV input voltage are normal
Hard Fault	Hardware protection got triggered	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
Backup OP	Output power over limitation on back-up side	Check whether the load power on back-up side exceeds the maximum output power of inverter.
Inverter OV	The load power exceeds the range	(1). Check whether there is an impact load on the back-up side and whether the load power is too high. (2). Check whether back-up side is short circuit.
Inverter OF	The load power exceeds the range	(1). Check whether there is an impact load on the back-up side and whether the load power is too high. (2). Check whether back-up side is short circuit.
Inverter OC	The load power exceeds the range	(1). Check whether there is an impact load on the back-up side and whether the load power is too high. (2). Check whether back-up side is short circuit.
SCI Fault	Internal communication got failed. Caused by a strong external magnetic field etc.	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
FLASH Fault	Internal storage anomaly. Caused by a strong external magnetic field etc.	(1). Restart the inverter. (2). If the problem persists, contact the installation company.
Meter Comm Fault	Abnormal communication between meter and inverter.	(1). Check whether the communication connection. between inverter and meter is reliable. (2). Confirm whether the meter model is compatible and if the settings are correct.
BMS Comm Fault	Abnormal communication between inverter and battery BMS.	(1). Check whether the battery ID selection is correct. (2). Check whether the communication connection between inverter and BMS is reliable. (3). Check the working status of battery.

7 Storage & Care

7.1 System Storage

If the inverter is not immediately put into service within 2 months from the production date, the storage specifications needs to be met as follow:

- The inverter should be stored indoors, not in direct sunlight or rain. The environment should be dry, clean and well ventilated, there should be no organic solvents or corrosive gases, conductive metal dust, and it should be located away from heat and fire sources.
- After the storage period has passed, the product must be inspected and tested by professional personnel before it can be put into use. During storage, relevant certificates that meet the product's storage requirements, such as temperature and humidity records, photos of the storage environment and inspection reports, should be kept.
- Do not remove the outer packaging of the inverter.
- Storage temperature should be maintained at -20°C~+60°C; Relative humidity should be maintained at 5% relative humidity ~ 95% relative humidity.
- Handle the inverter with care to avoid personal injury or damage to the equipment caused by its weight.
- Regular inspections must be carried out during storage. The packaging must be intact. If the packaging is damaged, it should be replaced immediately.
- After the system has been idle for a long time, the inverter and photovoltaic devices and batteries should be inspected and tested by professionals before they can be put into operation.

7.2 System Care

Firmware update

In order to benefit from the warranty, it is a prerequisite that the inverter is connected to the WiFi network via the dongle provided. Updating the firmware is critical to optimize inverter performance and warranty.

Normally the WECO team updates the system remotely, so always keep the inverter online to avoid missing the update.

During the upgrade, the system may operate in bypass mode (directly using mains power). Make sure the inverter is in normal condition and the Internet connection is stable, then press the update button in the NOOR application to start the system update. When your inverter loses WIFI or is not online, it will no longer be remotely monitorable and you will not be able to receive notifications or email alerts and warnings, a prolonged disconnection from the WiFi network for more than 30 days will cause you to lose your right to the additional warranty.

The inverter must be connected to the Internet via 2.4 Ghz home WIFI. Smartphone hotspot is only possible as a backup connection in case of loss of WIFI. Check the NET light on the WIFI dongle to see whether the WIFI connection is successful or not.

ATTENTION

Critical updates must be performed within 60 days of publication or the additional warranty will be voided.

Updates can also be performed via bluetooth APP locally, without the need for a WiFi network; however, your cell phone will need to be connected to the 4 or 5G network to act as an automatic router.

8 Inverter Disposal

8.1 Remove the inverter

Procedure:

Step 1: perform a system shutdown operation (see 6.3 System Shutdown).

Step 2: Wait 15 minutes, make sure there is no residual voltage in the connections. Then disconnect all electrical connections to the inverter, including signal lines, PV input lines, battery input lines, AC output lines, and protective grounding cables.

Step 3: Remove the screws securing the inverter.

Note: Please note that for any reason, personnel or installer should not disassemble/demolish the inverter without WECO's permission, otherwise the device will not be under warranty.

8.2 Packaging inverters

If you have the original packaging of the inverter, insert it into the original packaging and seal it tightly with tape.

If you can no longer find the original inverter packaging, use a wooden box suitable for the weight and size of the inverter to seal it tightly.

8.3 Scrap inverters



At the end of the inverter's useful life, dispose of it in accordance with the electrical waste disposal law in force at the place of installation.



Appendix A abbreviations









A	
AC	Alternating Current
D	
DC	Direct Current
I	
ID	Identifier
L	
LED	Light Emitting Diode
LVRT	Low Voltage Ride-Through
M	
MPPT	Maximum Power Point Tracking
P	
PC	Personal Computer
PE	Protective Earthing
PV	Photovoltaic
R	
RCD	Residual Current Device
RH	Relative Humidity
S	
SN	Serial Number
T	
THDI	Total Harmonic Current Distortion
WEEE	Waste Electrical and Electronic Equipment
WiFi	Wireless Fidelity









Appendix B Label Description









Nameplate









WECO Model: TK-40K-HC Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	60*2Ad.c.
Isc PV:	80*2Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	48.0kVA
On-grid Input Max. Current:	69.6Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	40kW
On-grid Output Rated Apparent Power:	40kVA
On-grid Output Max. Apparent Power:	44kVA
On-grid Output Max. Current:	66.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	40kW
Off-grid Output Rated Apparent Power:	40kVA
Off-grid Output Max. Apparent Power:	44kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	48kVA
Generator Input Max. Current:	69.6Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecoosure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WeCoSRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com	
	
	
User Manual	









WECO Model: TK-50K-HC Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	60*2Ad.c.
Isc PV:	80*2Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	60.0kVA
On-grid Input Max. Current:	87.0Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	50kW
On-grid Output Rated Apparent Power:	50kVA
On-grid Output Max. Apparent Power:	55kVA
On-grid Output Max. Current:	83.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	50kW
Off-grid Output Rated Apparent Power:	50kVA
Off-grid Output Max. Apparent Power:	55kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	60kVA
Generator Input Max. Current:	87.0Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecoosure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WeCoSRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com	
	
	
User Manual	

WECO Model: TK-25K-XL Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	30*4Ad.c.
Isc PV:	40*4Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	30kVA
On-grid Input Max. Current:	43.5Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	25kW
On-grid Output Rated Apparent Power:	25kVA
On-grid Output Max. Apparent Power:	27.5kVA
On-grid Output Max. Current:	42.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	25kW
Off-grid Output Rated Apparent Power:	25kVA
Off-grid Output Max. Apparent Power:	27.5kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	30kVA
Generator Input Max. Current:	43.5Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecostructure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WECO SRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com     	
   User Manual	

WECO Model: TK-30K-XL Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	30*4Ad.c.
Isc PV:	40*4Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	36kVA
On-grid Input Max. Current:	52.2Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	30kW
On-grid Output Rated Apparent Power:	30kVA
On-grid Output Max. Apparent Power:	33kVA
On-grid Output Max. Current:	50.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	30kW
Off-grid Output Rated Apparent Power:	30kVA
Off-grid Output Max. Apparent Power:	33kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	36kVA
Generator Input Max. Current:	52.2Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecostructure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WECO SRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com     	
   User Manual	

WECO Model: TK-36K-XL Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	30*4Ad.c.
Isc PV:	40*4Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	43.5kVA
On-grid Input Max. Current:	63.0Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	36kW
On-grid Output Rated Apparent Power:	36kVA
On-grid Output Max. Apparent Power:	39.6kVA
On-grid Output Max. Current:	60.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	36kW
Off-grid Output Rated Apparent Power:	36kVA
Off-grid Output Max. Apparent Power:	39.6kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	43.5kVA
Generator Input Max. Current:	63.0Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecostructure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WECO SRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com     	
   User Manual	

WECO Model: TK-40K-XL Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	30*4Ad.c.
Isc PV:	40*4Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	48.0kVA
On-grid Input Max. Current:	69.6Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	40kW
On-grid Output Rated Apparent Power:	40kVA
On-grid Output Max. Apparent Power:	44kVA
On-grid Output Max. Current:	66.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	40kW
Off-grid Output Rated Apparent Power:	40kVA
Off-grid Output Max. Apparent Power:	44kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	48kVA
Generator Input Max. Current:	69.6Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecostructure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WECO SRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com     	
   User Manual	

WECO Model: TK-50K-XL Hybrid Inverter	
PV Input Port	
PV Max. Input Voltage:	1000Vd.c.
PV Max. Input Current:	30*4Ad.c.
Isc PV:	40*4Ad.c.
PV MPPT Voltage Range:	200-850Vd.c.
Battery Input Port	
Battery Voltage Range:	135-750Vd.c.
Battery Max. Charge/Discharge Current:	100/100Ad.c.
Battery Type:	Li-Ion
Grid Output/Input Port	
On-grid Input Max. Apparent Power:	60.0kVA
On-grid Input Max. Current:	87.0Aa.c.
On-grid Input Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Input Nominal Frequency:	50/60Hz
On-grid Output Rated Power:	50kW
On-grid Output Rated Apparent Power:	50kVA
On-grid Output Max. Apparent Power:	55kVA
On-grid Output Max. Current:	83.0Aa.c.
On-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
On-grid Output Nominal Frequency:	50/60Hz
On-grid Power Factor:	0.8 leading ... 0.8 lagging
Back-up Output Port	
Off-grid Output Rated Power:	50kW
Off-grid Output Rated Apparent Power:	50kVA
Off-grid Output Max. Apparent Power:	55kVA
Off-grid Output Nominal Voltage:	3/N/PE~380/400Va.c.
Off-grid Output Nominal Frequency:	50/60Hz
Generator Port	
Generator Input Max. Apparent Power:	60kVA
Generator Input Max. Current:	87.0Aa.c.
Generator Input Nominal Voltage:	3L/N/PE~380/400Va.c.
Generator Input Nominal Frequency:	50/60Hz
General Information	
Operating Temperature Range:	-30...+60°C
Ecostructure:	IP65
Protection Class:	I
Operating Altitude:	3000m
Communication:	CAN, RS485, WiFi/LAN (Optional)
Inverter Topology:	Non-isolated
Over Voltage Category:	II(PV), III(Main)
WECO SRL Viale Kennedy 113-121 Scarperia e San Piero, Firenze, Italy E-mail: service@wecobatteries.com     	
   User Manual	

Appendix C Technical Datasheet

	TK-25K-XL	TK-30K-XL	TK-36K-XL	TK-40K-XL	TK-50K-XL
PV Input					
Start-up voltage (V)	135	135	135	135	135
Max. DC input voltage (V)*	1000*	1000*	1000*	1000*	1000*
Rated DC input voltage (V)	620	620	620	620	620
MPPT voltage range (V)*	200-850*	200-850*	200-850*	200-850*	200-850*
No. of MPP trackers	4	4	4	4	4
No. of DC inputs per MPPT	2	2	2	2	2
Max. input current (A)	30*4	30*4	30*4	30*4	30*4
Max. short-circuit current (A)	40*4	40*4	40*4	40*4	40*4
Battery Side					
Battery type	Lithium Battery (with BMS)				
Battery communication mode	CAN	CAN	CAN	CAN	CAN
Battery voltage range (V)	135-750	135-750	135-750	135-750	135-750
Maximum charging current (A)	100	100	100	100	100
Maximum discharge current (A)	100	100	100	100	100
Grid Side					
Rated output power (kW)	25.0	30.0	36.0	40.0	50.0
Max. output power (kW)	27.5	33.0/30.0 ^①	39.6	44.0	55.0
Rated output apparent power (kVA)	25.0	30.0	36.0	40.0	50.0
Max. output apparent power (kVA)	27.5	33.0/30.0 ^②	39.6	44.0	55.0
Max. input apparent power (kVA)	30.0	36.0	43.5	48.0	60.0
Max. charging power of battery (kW)	25.0	30.0	36.0	40.0	50.0
Rated AC voltage (V)	3L/N/PE, 220/380V; 230/400V; 240/415V				
Rated AC frequency (Hz)	50/60	50/60	50/60	50/60	50/60
Rated output current (A)	38	43.5	52.0	60.0	75.0
Max. output current (A)	42	50.0/43.5 ^③	60.0	66.0	83.0
Max. input current (A)	43.5	52.2	63.0	69.6	87.0
Power factor	0.8 leading ...0.8 lagging				
Max. total harmonic distortion	<3% @Rated output power				
DCI	<0.5%In				
Back-up Side					
Rated output power (kW)	25.0	30.0	36.0	40.0	50.0
Max. output power (kW)	27.5	33.0	39.6	44.0	55.0

Rated output apparent power (kVA)	25.0	30.0	36.0	40.0	50.0
Max. output apparent power (kVA)	27.5	33.0	39.6	44.0	55.0
Rated output current (A)	38.0	43.5	52.0	60.0	75.0
Max. output current (A)	42.0	50.0	60.0	66.0	83.0
UPS switching time	<20ms	<20ms	<20ms	<20ms	<20ms
Rated output voltage (V)	3L/N/PE, 220/380V; 230/400V; 240/415V				
Rated output frequency (Hz)	50/60	50/60	50/60	50/60	50/60
Peak output apparent power (kVA)	30,60s	36,60s	43.5,60s	48,60s	60,60s
Voltage harmonic distortion	<3% @Linear load				
Generator Side					
Max. input apparent power (kVA)	30.0	36.0	43.5	48.0	60.0
Max. charging power of battery (kW)	25.0	30.0	36.0	40.0	50.0
Rated AC voltage (V)	3L/N/PE, 220/380V; 230/400V; 240/415V				
Rated AC frequency (Hz)	50/60	50/60	50/60	50/60	50/60
Max. input current (A)	43.5	52.2	63.0	69.6	87.0
Efficiency					
Max. efficiency	98.8%	98.8%	98.8%	98.8%	98.8%
European efficiency	98.3%	98.3%	98.3%	98.3%	98.3%
Protection					
DC reverse polarity protection	Integrated	Integrated	Integrated	Integrated	Integrated
Battery input reverse connection protection	Integrated	Integrated	Integrated	Integrated	Integrated
Insulation resistance protection	Integrated	Integrated	Integrated	Integrated	Integrated
Surge protection	Integrated	Integrated	Integrated	Integrated	Integrated
Over-temperature protection	Integrated	Integrated	Integrated	Integrated	Integrated
Residual current protection	Integrated	Integrated	Integrated	Integrated	Integrated
Islanding protection	Integrated(Frequency shift)				
AC over-voltage protection	Integrated	Integrated	Integrated	Integrated	Integrated
Overload protection	Integrated	Integrated	Integrated	Integrated	Integrated
AC short-circuit protection	Integrated	Integrated	Integrated	Integrated	Integrated
General Data					
Over voltage category	PV:II;Main:III		PV:II;Main:III		
Dimensions (mm)	800*620*300 (W*H*D)		800*620*300 (W*H*D)		
Weight (KG)	72	72	72	72	72
Protection degree	IP65	IP65	IP65	IP65	IP65

Standby self-consumption (W)	<15	<15	<15	<15	<15
Topology	Transformerless		Transformerless		
Operating Temperature Range (°C)	-30~60	-30~60	-30~60	-30~60	-30~60
Relative Humidity (%)	0~100	0~100	0~100	0~100	0~100
Operating Altitude (m)	3000(>3000m derating)		3000(>3000m derating)		
Cooling	Smart fan		Smart fan		
Noise Level (dB)	<50	<50	<50	<50	<50
Display	OLED & LED		OLED & LED		
Communication	CAN,RS485,WiFi/LAN(Optional)		/	/	CAN,RS485,WiFi/LAN(Optional)

- ① AS4777.2&VDE-AR-N 4105:30.0KW
 - ② AS4777.2&VDE-AR-N 4105:30.0KVA
 - ③ AS4777.2&VDE-AR-N 4105:43.5A
- *PV Max.Input voltage is 850V.

	TK-40K-HC	TK-50K-HC
PV Input		
Start-up voltage (V)	135	135
Max. DC input voltage (V)*	1000*	1000*
Rated DC input voltage (V)	620	620
MPPT voltage range (V)*	200-850*	200-850*
No. of MPP trackers	2	2
No. of DC inputs per MPPT	3	3
Max. input current (A)	60*2	60*2
Max. short-circuit current (A)	80*2	80*2
Battery Side		
Battery type	Lithium Battery (with BMS)	
Battery communication mode	CAN	CAN
Battery voltage range (V)	135-750	135-750
Maximum charging current (A)	100	100
Maximum discharge current (A)	100	100
Grid Side		
Rated output power (kW)	40.0	50.0
Max. output power (kW)	44.0	55.0
Rated output apparent power (kVA)	40.0	50.0
Max. output apparent power (kVA)	44.0	55.0
Max. input apparent power (kVA)	48.0	60.0
Max. charging power of battery (kW)	40.0	50.0
Rated AC voltage (V)	3L/N/PE,220/380V;230/400V;240/415V	
Rated AC frequency (Hz)	50/60	50/60
Rated output current (A)	60.0	75.0
Max. output current (A)	66.0	83.0
Max. input current (A)	69.6	87.0
Power factor	0.8 leading ...0.8 lagging	
Max. total harmonic distortion	<3% @Linear load	
DCI	<0.5%In	
Back-up Side		
Rated output power (kW)	40.0	50.0
Max. output power (kW)	44.0	55.0

Rated output apparent power (kVA)	40.0	50.0
Max. output apparent power (kVA)	44.0	55.0
Rated output current (A)	60.0	75.0
Max. output current (A)	66.0	83.0
UPS switching time	<20ms	<20ms
Rated output voltage (V)	3L/N/PE,220/380V;230/400V;240/415V	
Rated output frequency (Hz)	50/60	50/60
Peak output apparent power (kVA)	48,60s	60,60s
Voltage harmonic distortion	<3% @Linear load	

Generator Side		
Max. input apparent power (kVA)	48.0	60.0
Max. charging power of battery (kW)	40.0	50.0
Rated AC voltage (V)	3L/N/PE,220/380V;230/400V;240/415V	
Rated AC frequency (Hz)	50/60	50/60
Max. input current (A)	69.6	87.0
Efficiency		
Max. efficiency	98.8%	98.8%
European efficiency	98.3%	98.3%
Protection		
DC reverse polarity protection	Integrated	Integrated
Battery input reverse connection protection	Integrated	Integrated
Insulation resistance protection	Integrated	Integrated
Surge protection	Integrated	Integrated
Over-temperature protection	Integrated	Integrated
Residual current protection	Integrated	Integrated
Islanding protection	Integrated(Frequency shift)	
AC over-voltage protection	Integrated	Integrated
Overload protection	Integrated	Integrated
AC short-circuit protection	Integrated	Integrated
General Data		
Over voltage category	PV:II;Main:III	PV:II;Main:III
Dimensions (mm)	800*620*300 (W*H*D)	800*620*300 (W*H*D)

Weight (KG)	72	72
Protection degree	IP65	IP65
Standby self-consumption (W)	<15	<15
Topology	Transformerless	Transformerless
Operating Temperature Range (°C)	-30~60	-30~60
Relative Humidity (%)	0~100	0~100
Operating Altitude (m)	3000(> 3000m derating)	
Cooling	Smart fan	
Noise Level (dB)	<50	<50
Display	OLED & LED	
Communication	CAN,RS485,WiFi/LAN(Optional)	


*PV Max.input voltage is 850V.

Appendix D Working Mode & Light Language

The TK inverter can manage PVs through the use of MPPT, can perform three-phase DC to AC conversion through the inverter circuit, and has a surge protection function on both the DC and AC sides.

The TK inverter supports the use of storage batteries; power generated by the PV string is supplied to the local load for use, and excess power is stored in the battery. The electricity stored in the battery can be released to the grid depending on the load situation and settings chosen by the user.

Schematic:



Note!

The TK inverter wiring diagram above applies to the wiring rules that require the EPS N (neutral) wire to be disconnected from the grid N (neutral) wire, applicable to most countries in the world.

For some countries, these countries require wiring rules that require the N (neutral) wire of other power sources not to be insulated or switched/connected with PE. Therefore, if you do not know the local regulations, please contact a local professional institution for confirmation.

Check household loads and make sure they are within the "BACK-UP/EPS power rating" in EPS mode, otherwise the inverter will shut down with an "overload fault" warning. Check with the power grid operator if there are special regulations for grid connection.




Description of the LEDs

The LED Bar is described in the following table

Equipment status	Light language	remarks
Standby	Blink blue light once for 6s (3S lights on, 3S lights off)	The device is normal and in standby
On-Grid Work	Blinking green light once for 6s (3S lights on, 3S lights off)	
Off-Grid Work	Blinking green light once for 3s (0.5S lights on, 2.5S lights off)	
Alarm	Blinking orange light once for 3s (1.5S lights on, 1.5S lights off)	Recoverable alarm automatic recovery
Fault	Fixed Red Light	The failure causes the system to stop working and requires manual maintenance.
Updating	Fixed White Light	The system is updating.

Description of Operation Modes




Inverter has the following basic operation modes and you can configure the operation mode as per your preference in the App.

Mode Type	Scenario	Brief Description
Auto Mode		In this working mode, when the power from the PV array is sufficient, PV power will supply the loads, battery, and grid in the order of loads first, battery second, and grid last. (You can set the power to the grid to 0W when the local grid doesn't allow inverter power to feed to the grid).
		When the PV power is insufficient, the battery will discharge to supply loads, and the grid will join in if the battery is not enough to supply loads.
Peak load Shifting (Load Shifting)		Set the maximum power Pmax (kVA) contracted with the grid. When the load consumption is less than the Pmax, the PV will charge the battery first, and the grid supplies the load. When the battery is full, PV will supply the load together with the grid.

Mode Type	Scenario	Brief Description
	<p>PV</p> <p>Battery</p> <p>Inverter</p> <p>Grid</p> <p>Loads</p> <p>$P_{load} > P_{max}$</p>	<p>When the load consumption exceeds the P_{max}, the inverter will take power from the battery and PV to supply power to the load to compensate for the power that exceeds the P_{max}.</p>

**To realize the "Peak load Shifting" function, the load power that exceeded P_{max} has to be within the inverter max output power, otherwise, the inverter will only output the max power which allowed.*

Mode Type	Scenario	Brief Description
UPS Mode	<p>PV</p> <p>Battery</p> <p>Inverter</p> <p>Grid</p> <p>Loads</p>	<p>In this working mode, the inverter will use the power from PV or grid to charge the battery until it is fully charged, and as long as the grid is there, the battery won't discharge.</p>
	<p>PV</p> <p>Battery</p> <p>Inverter</p> <p>Grid</p> <p>Back-up Loads</p>	<p>When the grid fails, power from PV and battery will supply loads connected on the back-up side (UPS).</p>
Economic Mode	<p>PV</p> <p>Battery</p> <p>Inverter</p> <p>Grid</p> <p>Loads</p>	<p>In this working mode, you can set charge/dis-charge power and time in the App, inverter will use the power from PV or grid (whether to use can be set in the App) to charge the battery in the predetermined period.</p>

Mode Type	Scenario	Brief Description
		<p>Inverter will use power from PV and battery to supply loads in the predetermined period and the insufficient part will be supplied by the grid.</p>
Off-grid Mode		<p>In the purely off-grid mode, power from PV will supply the back-up loads first and then charge the battery if there's surplus power.</p>
		<p>When the power from PV isn't enough, the battery will discharge to supply back-up loads together with PV.</p>

Appendix E Noor APP User Guide

App Introduction

Function

Through the application, alarm querying, parameter configuration, daily maintenance, debugging and other functions can be realised, and it is a convenient maintenance platform.

Connection method

Precondition

Make sure the WIFI module is correctly connected to the ESY inverter.

After the DC side or AC side of the inverter is power on, it can be connected to the APP through WIFI module and external router:

Statement

The interface shown in this application is Noor V1.1.0. The image is for reference only and the interface of the specific application prevails.

The company has the right to final interpretation of this document and all documents related to this product.

Subject to updates, revisions or discontinuation without notice, please visit our official website for the latest product information.

Download and install the app



Download method : Search for "Noor" in the Google Play or App Store.

Mobile phone system requirements : Supports use on IOS 12.0 and Android 8.1.0 or higher.




Register a Noor APP account

Precondition

The DC or AC side of the inverter is powered on.

WIFI module is connected to the ESY inverter.

The phone is connected to the network.



Procedure

If you do not have a Noor App user account, register following these steps:

Steps :

1. Go to the Noor App login page, click "Register Now!" at the bottom.
2. Complete the user account registration according to the prompts on the page. Fill in the registration information: country (required), email number (required), verification code (required), password (required), re-enter password (required), and finally check the user agreement and privacy registration to register.
3. After account registration, users can log in to the Noor App with the account name and password.


Login and Logout of the APP

Login APP

Steps :

On the mobile desktop, use the Noor App application icon to login.

On the app login page, enter your account and password, then click "Sign in".




Logout APP

Steps :

Click "☰" in the upper left corner of the main page, and a pop-up page will appear on the left side.

On the pop-up page that slides out, click the "🚪" icon to log out.



Build a Power Station Wizard

Precondition


After completing the device commissioning, you can use Noor App to create a power station and configure the basic information, which enables centralized monitoring and management of the devices.

Login at the first time to create an initial power station

Step1: After logging in to the Noor App, you can click the "Add plant" button to add a power station.

Step2: You can fill in the information for the power station on the page, and then click the "Save" button to save the information and exit to the main page.

Step3: If there is no device in the power station, you can click the "Add Device" button to add devices. Refer to section Build new device" for more information.




Add a power station

Step1: Click "☰" in the upper left corner of the main page, and a page will slide out from the left side.

Step2: Click on the "Plant Management" button in the slide-out page to view the power station list.

Step3: Click the "+" button in the upper right corner of the power station list page to enter the page for adding a power station.

Step4: After filling in the power station information, use "Save" button to save.



Add new device

After the power station is created, if you want to add new device to the power station, you can add the new device to a power station by this function.

Step 1: Click the "Add Device" icon on the home page.

Step 2: Click the "Data Logger" icon.

Step 3: Scan or identify the QR code of the data collector from the album. This QR code is the device SN information.

If the QR code is damaged or the scanning is abnormal, you can click "✍️" to enter the SN.


Step 4: After scanning or filling in the SN, enter the device name (name the device).


Step 5: Click "Adding" to add; If you need to continue configuration steps, click "Smart config", otherwise click "Exit" to return to the homepage.




Note!

1. Please note that one device/inverter cannot be added to two plants or above, if you're an installer and using your own account, please delete the device/inverters after finishing the installation and debug of inverter. If you're the owner or user of the inverter, if you want to add a current device to another plant, please delete the device from the current plant first then to proceed adding to another plant.
2. Once the device is deleted from plant, the history data of related plant or device will be deleted. Please be careful about deleting of device/plant.





Step 6: After clicking “Smart Config” follow the steps below to connect the inverter to the local internet connection.





Check the plant status

The Noor App provides an overview of the power station, real-time status overview of the power station, energy output and consumption, revenue, energy flow diagrams, and other information.

View the details of the plant

After logging in to the App, you can view the details of the current plant, or you can click the "Demo_Plant" icon on the "Home Page" and select the name of the plant to view the details of the plant.



Device information:

Displays the serial number of the current device and the time of the last data update

Real-time operating status:

Displays system status, working mode, and power supply direction of the devices system under the plant.

Today's information:

CO2 emission reduction and today's energy information such as photovoltaic, power grid, battery, load, etc.

Energy charts:

The energy usage status of the devices system under the plant at different times and dimensions helps analyze the trend of energy trends.



Note!

The system has the following status:


Offline: The device is offline or the WIFI module is not connected to the network (Please keep system online).

Bypass: The device is in BYPASS mode (inverter not using PV or battery power), grid power will allow to through inverter to power the load.

On Grid: The inverter is connected on grid.

Off Grid: The inverter is working in EPS mode.

Grid Check: The process of switching from off-grid to on-grid when photovoltaic is in place.



Inverter Setting:

Enable remote configuration of device system operating parameters.

Running Info:

Display detailed real-time operational information of the device system, such as voltage, current, power, etc.

Link to Manuals:

Link to WECCO company website from which the related documentations of ESY series inverter can be viewed or download.

Plant Management:

View the list of plants and perform adding, deleting and editing of corresponding plant.

Device Management:

View the list of devices and perform adding, deleting and editing of corresponding device.




Account Management

Edit the account name, Email and password

Fault message



Click "Warning" to view the device current/historical event messages under plant.



Warning:

Display the fault alarm records of the device that are currently occurring/have been restored.

Upgrade :

Display firmware update records that have occurred on the device.

Energy Information

On the main interface, select "Energy charts" to view energy information, as shown below.

Select time:
Click the " < 2024-01-24 > " area to select the data view on the specified date.

Select parameters:
Click the " Select Param v " area to select the parameters that need to be viewed for comparative analysis.

Basic settings

On the "Home Page > ☰ > Basic Setting" tabs, remote parameter settings can be made for the device system under the current plant. The configuration page is divided into basic settings and advanced settings, and can be switched by sliding left and right.


The Basic Setting page includes the following configuration options:

- Date: 2024.05.21 >
- Time: 13:33:00 >
- Work Mode:
 - Auto Mode:
 - Peak Shaving: Enter edit
 - Battery Priority:
- Battery Setting:
 - Battery Type: Lithium >
 - OnGrid DOD: 70% >
 - OffGrid DOD: 80% >
 - Battery Discharge Power: 50% >
 - Battery Charge Current: 100A >


Set working mode

In the inverter setting page, three working modes can be configured for the current power station: Auto mode, Peak Shaving and Battery Priority. The home page can display the working mode status of the current power station.

Basic Setting>>Work Mode>>Mode Select



Basic Setting>>Work Mode>>Peak Shaving>>Enter edit



Auto mode

The priority of photovoltaic energy production is to ensure load operation, so the remaining photovoltaic energy is charged into the energy storage battery. After the battery has been fully charged, or if there is energy surplus, the excess energy can be fed into the grid (the feed-in function can only be used with the permission of the grid company).

Peak Shaving

The system can operate according to the set time and power, use the PV and batteries when electricity prices are high, use the grid and charge the batteries when electricity prices are low, and sell the remaining electricity generated by the PV to the grid during the day (with the permission of the grid company before using the feed-in function), can save on electricity costs. In the planning mode, the charging and discharging period and the corresponding power must be set.

Description : In the process of setting the planning mode, the charge/discharge time periods cannot overlap.

Battery Priority

In this mode, the system prioritizes charging the battery until fully charged. The battery will be discharged only when there is no other power source available.




Note!

Before configuring the working mode, please refer to Appendix D working mode & Light Language to understand the use scenarios and working mode

Date & Time setting

Basic Setting>>Date and Time Setting



Date:

Current date. The inverter's statistical function will be performed based on this set date.


Time:

The current time, the system's planning mode, will match this set time.

Battery Setting

Set Battery Type


In the battery type, two types of batteries can be configured: Lithium and Lead-acid.



Set Battery parameters

If battery type set to Lithium:

Settable functions: On Grid DOD, Off Grid DOD, Battery Discharge Power, Battery charge Power



OnGrid DOD:

The lower limit of the discharge SOC when inverter On grid. When SOC < (100% subtraction this value), the battery will keep battery energy for Off grid using

OffGrid DOD:

The lower limit of the discharge SOC when inverter Off grid. When SOC < (100% subtraction this value), the battery will stop discharge battery energy until back to on grid.

Battery Discharge Power:

Set the maximum discharge power of the battery.

Battery Charge current:

Set the max charging current from the inverter.

**Note!**

Above is the lithium battery setting of the inverter side, there are also some settings requested from the battery side. (Refer to battery manufacture manual). To ensure enough power for EPS load use when there's grid outage, make sure offGrid DOD is 5% more than onGrid DOD. e.g. onGrid DOD = 75% and offGrid DOD = 80%.

If battery type set to Lead-acid:

Settable functions: Protection Alarm V, Bulk Charge V, Float Charge Voltage, AH Setting, EndOff Voltage, Min Disch V, Disch.Hysteresis Voltage, Battery Discharge Power, Battery Charge Current.

Battery Setting	
Battery Type	Lead-Acid >
Prtoection Alarm V	56V >
Bulk Charge V	56V >
Float Charge Voltage	54V >
EndOff Voltage	40.5V >
AH Setting	150A >
Min Disch V	44V >
Disch. Hysteresis Voltage	2V >
Battery Discharge Power ?	100% >
Battery Charge Current ?	97A >

Protection Alarm V:

Charge cut-off voltage, to protect the battery from over-charge

Bulk Charge V:

Future feature, not available now.

Float Charge Voltage:

Inverter will maintain battery voltage in this value by using small current charge & discharge

EndOff Voltage:

Discharge cut-off voltage, to protect the battery from over-discharge

AH Setting:

Battery capacity, to be set according to the lead-acid battery's actual AH capacity(Notice high AH will dangerous)

Min Disch V:

Future feature, not available now.

Disch.Hysteresis Voltage:

Future feature, not available now.

**Note!**

Since there are many types of lead-acid battery, above parameter setting shall refer to the datasheet or parameter label of the actual lead-acid battery used.

Expert settings (Authorized operator only)


On the "Home Page>☰® > Expert Setting" tabs, remote parameter settings can be made for the device system under the current plant. The configuration page can be switched by sliding left and right.

**Note!**

Expert Setting is available for authorized installer or engineer to operate. Please contact to the WECO service support for Expert Setting password.

Sys Setting

Settable functions: EPS Enable, PV Input Type, ISO Enable, ARC enable, Anti Reflux, Inverter AC Power (In/out)



EPS Enable: EPS enable switch. After setting the enable switch, the load will output and provide power after the inverter is off the grid.

ISO Enable: Insulation detection enable switch. When ISO detection is enabled, inverter will enable the insulation detection function.

ARC Enable: US test standards need to be set to enable.


Anti Refulex: Discharge the reverse current and set the enable so that the excess energy of the system will not be fed back to the power grid.

CT/Meter: CT/Meter is connected to Inverter

Inverter AC Power (In/out): When working alone, maximum power setting for the inverter, which is equal to rated power multiplied by percentage.

System setting and ON/OFF

The settings page is shown below. Settable functions: Restore Factory Setting, Remote Start UP/Shut Down.



Restore Factory Setting :


Erase any manual setting and returns to the original set up.

Remote Start UP/Shut Down :

Power up and power down the inverter.

Grid setting

Settable functions: Grid Standard, Grid set.




Grid Standard:

Select the region or national grid code, the voltage amplitude and frequency will be determined once it set. (Refer attached page for selection recommend).

Auto Test

If choose the Italy grid standard (CEI-021INTERNA), the Auto test function will be presented, and the inverter AUTO test can be performed.


Expert Setting>>Grid Setting>>CEI-021INTERNA(Italy Grid Standard)>>Auto Test





Device running information


You can view the detailed real-time operation information of the devices under the current plant such as basic information, photovoltaic, power grid, battery, and load, generator information.

Procedure:

On the "Home Page" > Click  > "Running Info" tabs, you can view detailed real-time run information of the device system under the current plant, such as voltage, current, power, etc.



The data also can be download by clicking , then select the data time period in which you want to download.




Device management

You can view the basic status of all devices added by the current plant.

To add a device, see chapter "Add new plant".


Procedure:

Step1 : Click the  icon in the upper left corner area of the homepage, and the page will pop up on the left side.

Step2 : Click "Device Management" to enter the list page.

Device information: You can view the basic information and operation status of all devices under the current plant.

Device deletion: Swipe left on the device you want to delete to appear the red delete button, click to confirm the pop-up window and delete the device from your account (**used for link device to new app account**)



Note!

When the user or installer decides to remove and delete the device/inverter from plant, after the operation of deleting on Noor APP, please note that any personnel or installer do not disassemble / tear down the inverter without authorization, otherwise the device will not be in warranty.


Plant Management


In the app, users can create plant, edit plant information, and delete plant. To create a plant, see Create a new plant.

View the list of power stations

Showcasing all the plant created, you can see when the plant was created and the energy generated by the devices system.

Procedure:


- Step1 : Click the  icon in the upper left corner area of the homepage, and the page will pop up on the left side.
- Step2 : Click "Plant Management" to enter the list page.



Edit plant information

According to the actual situation, the name of the plant, the address of the plant and other information can be edited.


Procedure:

Step1 : Click the  icon in the upper left corner area of the homepage, and the page will pop up on the left side.

Step2 : Click "Plant Management" to enter.


Step3 : On the "Plant Management" page, click the  icon in the upper right corner of the plant that needs to be edited.

Step4 : Modify the relevant content according to your actual needs, and then click "Save".



Delete the plant


Procedure:

Step1 : Click the  icon in the upper left corner area of the homepage, and the page will pop up on the left side.

Step2 : Click "Plant Management" to enter the plant list page.

Step3 : Select a plant to slide left and the "Delete" button will appear.

Step4 : Click "Delete" to display a confirmation pop-up window, click "OK" in the pop-up window to delete the selected plant.



**Note!**


Please note that one device/inverter cannot be added to two plants or above, if you're an installer and using your own account, please delete the device/inverters after finishing the installation and debug of inverter. If you're the owner or user of the inverter, if you want to add a current device to another plant, please delete the device from the current plant first then to proceed adding to another plant.

- Once the device is deleted from plant, the history data of related plant or device will be deleted. Please be careful about deleting of device/plant.

Link to Manuals

There are documentations about inverter's introduction, instruction on WECO Company website. By Noor App you can easily access to the website for any documentations about the ESY series inverter to be viewed or download for your further reference. The latest ESY inverter user manual or corresponding documentations obtained by the link/following procedure.


Procedure:

Step1 : Click the  icon in the upper left corner area of the homepage, and the page will pop up on the left side.

Step2 : Click "Link to Manuals" to enter the WECO Company inverter product page.

Step3 : Click "ESY SERIES INVERTERS" to enter the ESY/H-ESY serials inverter product page.

Step4 : Click "ESY" to enter the ESY serials inverter documentation download area page; then download the manuals as wanted.




Account Management

This page is suitable for account changes, including Personal Avatar, Name, Email and password.

Procedure:

Step1 : Click "Account Management" to enter Account Management page.

Step2 : Modify the relevant content according to your actual needs.



Setting

This page is suitable for account cancel and APP detail review for Service Agreement and Privacy Policy.

Cancel Account

Procedure:

Step1 : Click "Setting" to enter Setting page.

Step2 : Click "Cancel Account" to enter cancel account page.

Step3 : Choose "Notice for account cancellation" and Click "Next".

