



TK Series Inverter 20-50K Quick Installation Guide

Installation requirements

1

When installing the inverter, a certain amount of space must be set aside around it to ensure that there is sufficient room for installation, maintenance and heat dissipation. The recommended installation height is 1500 mm.



Inverter Installation

Use the bracket to locate the position of the holes on the wall.





Drill the holes using a drill, install the expansion anchors, and attach the bracket to the wall.

Install the bracket on the back of the inverter and snap the inverter onto the wall bracket.



System Connections



PE Cable Connection



5 Grid and Back-UP Cables Connection



4



Meter Connection

Below is the definition of the terminals according to the meter model, ACR10R / RMM.





Batetry Cable Connection





BV Cables Connection



WiFi Module Installation



10 Power up the system and put it into operation



9

9	
Login	
R	+
	The user does not have Plant, please create.
A Enter account	Add Plant
Enter password	
Sign In	<u>=</u> ⊚ weco ess∽ []
Register	
Remeber Me Forgot password	
	Plant not bound device, Please scan device QR code to add.
Register and log in with user account	Add Device
	Add plant and add device in the plant

